





7 Verkstedmeny

Verkstedmenyen tilbyr følgende innstillingsmuligheter:

- Konfigurasjonendring for betjening av EasyStart Pro
- Funksjonstilpasning (visning, vedlikehold, tilbakestilling til fabrikkinnstillinger etc.)
- Apparatinfo for EasyStart Pro (hard- og software-versjon)
- Lese ut og slette feilminnet for varmeapparat og betjeningsselement

7.1 Åpne verkstedmeny

For å komme til verkstedmenyen åpnes menyen Innstillinger  og deretter holdes BACK-tasten  inne i mer enn 2 sekunder mens klokkesymbolet blinker under tannhjulet.



7.5.2 Lese ut feilminnet

I menyen [Feilminne] lagres feilmeldinger fra EasyStart Pro og alle tilkoblede varmeapparater. De kan leses ut, og etter at feilen er rettet kan hver enkelt feil slettes.



- Bekreft menyen ved å trykke på betjeningsknappen.
- Velg [Betjeningsselement] eller [Varmeapparat] ved å dreie betjeningsknappen.

DTC	Error
P000301	HW - Watch Dog Reset
P000302	HW - To many Watch Dog resets
P00030A	CAN - Kommunikationsfehler
P001700	Lack of devices on CAN (no heaters)
P001701	Change of devices on CAN (Mismatch)
P001702	External Temp. sensor defect (short cut)
P001703	External Temp. sensor defect (interruption)
P001707	Internal Temp. sensor defect (short cut)
P001708	Internal Temp. sensor defect (interruption)
P00170C	Control knop jammed
P001706	Push button jammed
P00170A	Clock not calibrated
P001709	Missing data
P001704	Fatal internal error
P001705	External Flash defect (TBD)
P00170B	Invalid configuration of the system